


Item # 545833XX (XX = 00-99, which represents different LED color temperature)

USE AND CARE GUIDE

LED 4 FT. STRIP LIGHT



Questions, problems, missing parts?
Call ETi SSL Customer Service
8:30 a.m. – 5 p.m., EST, Monday - Friday
1-855-ETI-SSLI (1-855-384-7754)
www.etissl.com

THANK YOU

Table of Contents

laple of Contents	
Safety Information	
Limited Warranty	
Pre-Installation	
Tools Required	
Package Contents	
Hardware Included	

Installation Instruction	4
Installation Instruction (continued)	6
Maintenance Instruction	
Environmental requirement	
Product carried standard	
Care and Cleaning	
Troubleshooting	

Safety Information



WARNING: Carefully read and understand the information given in this manual before beginning the assembly and installation. Failure to do so could lead to electric shock, fire, or other injuries which could be hazardous or even fatal.



WARNING: Ensure the electricity to the wires you are working on is shut off. Either remove the fuse or turn off the circuit breaker.



WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



WARNING: For safety, linked installations can be suspend Installation can only be conducted by the professional electrician, otherwise, there is a potential fire hazard.

NOTICE: Do not use this fixture with a dimmer switch.



WARNING: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15B of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- □ Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver,
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTICE: Minimum 75° supply conductors.

Limited Warranty


This product is warranted for a period of 5 years from the date of original purchase against defects in materials and workmanship. If this product should fail to operate due to defects in material or workmanship within 60 months of purchase, see www.etissl.com for details. This product will be repaired or replaced, at ETi's option. This warranty is expressly limited to repair or replacement of product and liability for direct, incidental, or consequential damages is hereby expressly excluded. Some states do not allow exclusions of direct, incidental or consequential damages so the above limitation of exclusion may not apply to you. This warranty gives the consumer specifc legal rights, which vary from state to state. WARRANTY IS VOID IF PRODUCT IS NOT USED FOR THE PURPOSE WHICH THIS PRODUCT IS MANUFACTURED.

Pre-Installation



NOTE: Keep your receipt and these instructions for proof of purchase.

TOOLS REQUIRED



PACKAGE CONTENTS


Part	Description	Quantity
Α	LED 4 FT. STRIP LIGHT	1



HARDWARE INCLUDED




Part	Description	Quantity
AA	Wire Nuts	3
BB	Aircraft Cable	2
CC	Mounting Screw (0.6in not included)	2
R	R Mounting Bracket (4in not included) (Comply with UL/cUL listed IFFX)	



Installation Instruction


1 Mounting to drywall

- □ Drill two hole (distance between two hole is 40.7in) in the ceiling.
- ☐ Make sure to fasten the combo wood-machine end into the metal hook.
- □ Tighten the Drywall Screw (not included) into the wood.




2 Mounting to wood

- □ Drill two hole (distance between two hole is 40.7in) in the ceiling to clear the closed flaps of the Toggle Bolt (not included).
- □ Make sure to fasten the toggle bolt into the butterfly nut before inserting the flaps into the ceiling.
- ☐ Tighten the toggle bolt.



3 Attaching the aircraft cable to the ceiling


□ Hang the aircraft cable (BB) on the ceiling.



Installation Instruction (continued)


4 Attaching the Strip Light to aircraft cable

- □ Install "S" shaped hook of aircraft cable (BB) on the LED Strip Light (A).
- □ Repeat this step on the other side of the LED Strip Light (A).
- □ Adjust aircraft cable to level light at the proper height by quick cabel-lock.




5 Connecting the electrical wires

- Connect the black wire and wire L together.
- Connect the white wire and wire N together.
- Connect the green wire and earth wire together.
- Cover the wire connection with the wire nuts (AA).



Installation Instruction (continued)

NOTICE: The Strip Light is Compatible for Battery Backup, and pls contact ETI SSL to puschase the Battery Backup (ETI Brand's model number is 90600143. Below is the wiring diagram.



Maintenance instruction

- 4.1 Do Not use volatile solvent such as alcohol to clean the troffer.
- 4.2 Use soft cotton cloth with suds to clean the troffer.
- 4.3 Non-professional Do not attempt to take apart and repair the troffer.
- 4.4 Please use the constant-current driver exclusively adaptive to the troffer, do not change the driver without permission .

Environment requirement

Operating temperature: -4 °F~113 °F.

Product carried standard

UL1598

Care and Cleaning



CAUTION: Before attempting to clean the fixture, disconnect the power to the fixture by turning the breaker off or removing the fuse from the fuse box.

Clean the fixture with a soft, dry cloth.

Do not use any cleaners with chemicals, solvents, or harsh abrasives.

Troubleshooting

Problem	Possible Cause	Solution
The fixture will not light.	The power is off.	Ensure the power supply is on.
	The circuit breaker is off.	Ensure the circuit breaker is in the on position.
The fuse blows or the circuit breaker trips when the light is turned on.	The wires are crossed or the power wire is grounding out.	Check the wire connections. Contact a qualified electrician or call the Customer Service Team at 1-855-384-7754.



Questions, problems, missing parts?
Call ETi SSL Customer Service
8:30 a.m. – 5 p.m., EST, Monday - Friday
1-855-ETI-SSLI (1-855-384-7754)
www.etissl.com

Retain this manual for future use.

rev. 2017.07.06

Imported by ETi Solid State Lighting, Inc. The Americas Headquarters 720 Corporate Woods Parkway Vernon Hills, IL 60061

Made in China